

StepWell™ Sanitizing Mats

Specialty Mats • Indoor

The StepWell mat provides an all-in-one solution for safely sanitizing shoes. It features a 2' x 3' well that holds an abrasive insert and your preferred liquid sanitizer, followed by a 3' x 5' carpeted section to help remove any excess moisture from shoes, reducing the likelihood of slips following sanitation. Wash, wipe, and walk on safely!



- Available in three designs
- The insert serves as a splash guard and helps dislodge any dirt or debris from the bottom of shoes so the fluid can reach the entire sole surface.
- Each mat includes one insert; additional inserts are available in packs of four
- Well holds one insert and approximately 84 ounces (2.5 L) of sanitizing solution (not included).
- Compatible with most sanitizing/disinfecting solutions. Works best with quaternary and hydrogen peroxide sanitizing solutions.



StepWell™ Mats

Specialty Mats • Indoor



Nylon Carpet

Nylon carpet dries shoes to reduce risk of slip-and-fall accidents and protect floors from moisture

Well with Insert

2'x3' well holds liquid sanitizer and abrasive insert to clean and disinfect shoes



The StepWell mat works best with quaternary and hydrogen peroxide sanitizing solutions; can be used with chlorine bleach solutions, but failure to adhere to recommended concentrate can damage the mat.

- Quaternary ammonium should be used per recommended dilution instructions on the label (for sanitizing level protection).
- 3% hydrogen peroxide solutions can be used without further dilution.
- 6% chlorine bleach should be used at a concentration of 0.4% (0.5 oz. per gallon). Caution: Do not use mat as a work surface to prepare bleach solution, as undiluted bleach may cause permanent color loss.

Product No. 835 (mat with insert)

Unit	Size (in.)	Shipping Weight
3' x 7' with insert	35" x 82"	17 lbs.

The StepWell mat does not come with sanitizing solution; it must be purchased separately.

Product No. 836 (inserts)

Unit	Size (in.)	Shipping Weight
Box of 4 inserts	20.5" x 33"	5 lbs.

Please note, mat sizes are approximate as rubber shrinks and expands in conjunction with temperature and time. Tolerable manufacturing size variance is 3-5%.